

⚠️ WARNING

- Before using this product, read and follow all of the instructions and warnings. Do not use this product if your pet is aggressive or is prone to aggressive behavior. Aggressive pets can cause severe injury and even death to their owner and others. If you are unsure whether this product is appropriate for your pet, please consult your veterinarian or a certified trainer.


⚠️ CAUTION

- It is vitally important that you and your pet remain safe while learning on-lead training. You must also be physically strong enough to restrain your pet when he tries to chase.

CAUTION

- Not for tie-out use.

What's Included





How it Works

The Premier Pet™ No Pull Comfort Harness is the perfect multi-functional harness, designed for maximum comfort, adjustability, and safety. The No Pull Comfort Harness is a versatile harness which is great for everyday use. The harness can be used as a standard harness or easily transition to a no pull harness. Reflective nylon and piping adds visibility in low light situations and the padded traffic handle is easy to grab when additional control is needed. For more control, use with the Premier Pet™ Multi-Functional Leash. This versatile, double-ended leash includes two leash snaps that attach to the front and back of the No Pull Comfort Harness, allowing safe and effective redirection of leash pulling.

Fitting the Harness


Fitting the Shoulder Straps

1. Open the quick-release buckles on the shoulder and girth strap.
2. Wrap and connect the shoulder straps around the dog's neck. The padded traffic handle should lie flat on the center of your dog's back with the wide end toward the dog's head.
3. Press your fingers on the lower front of the dog's chest to locate the breast bone. Adjust the shoulder straps and so that the front O-ring rests on or slightly above the breast bone (1A). *NOTE: This portion of the fitting is key—proper placement of the O-Ring is essential for your dog's comfort, as well as the effectiveness of the no pull function.*



Fitting the Girth Strap

1. Pull the Center Chest Strap between your dog's front legs (1B).
2. Adjust the girth strap for a comfortable snug fit. When fit properly, two fingers should barely fit between the fur and nylon strap. This prevents movement and chafing.
3. Once the desired fit is achieved, connect the quick-release buckle together (1C).



Going for a Walk

Back Leash Attachment

To use as a standard harness, attach your leash to the two D-Rings on the back of the harness. If your dog typically pulls on the leash, he will likely continue to do so because of the "opposition reflex". Opposition reflex is the reflex that causes sled dogs to pull against pressure.

No Pull Leash Attachment

Attach a nylon or leather 4-6 ft. leash to the D-Ring on the center chest strap of the harness.

Although the harness may have an immediate impact on your dog's pulling habits and it may be more manageable to walk him, he may still pull some while wearing it. The harness is designed to redirect your dog from pulling and help achieve a loose leash walk. The front chest leash attachment reduces pulling by steering your dog to the side and redirects his attention towards you. In addition, the Martingale Loop provides extra leverage for easy, relaxed control.

Going for a Jog or Run

The No Pull Comfort Harness is a great harness for everyday use, including running or jogging. However, proper fit of the harness is essential to the overall comfort of your dog. Be sure to fit the harness according to the fitting instructions. If your dog begins to chafe, stop using the harness and consult your veterinarian.

We suggest using only the back leash attachment when running. A leash attached to the Center Chest Strap during running could accidentally trip your dog.

Tips & Maintenance

- Check the harness regularly, especially on growing dogs. Over time and after multiple uses the harness may stretch or adjust.
- For more control, use with the Premier Pet™ Multi-Functional Leash. This versatile, double-ended leash includes two leash snaps that attach to the front and back of the No Pull Comfort Harness, allowing safe and effective redirection of leash pulling.
- Do not leave your dog unattended while wearing the harness.
- When not in use, safely store the harness.
- We don't recommend using a retractable leash with the no pull function, as the constant tension could encourage the dog to pull.
- Examine the harness for signs of chewing, fraying or damage.
- For more information, visit premierpet.com or call +1 (866) 381-2785.

Warranty

One Year Non-Transferable Limited Warranty

This product has the benefit of a limited manufacturer's warranty. Complete details of the warranty applicable to this product and its terms can be found at www.premierpet.com.

Premier Pet™

CH414-3055/1

Made in China

For important safety information, please see the product manual inside.
Radio Systems Corporation
10427 PetSafe Way, Knoxville, TN 37932 USA
+1 (866) 381-2785 | premierpet.com



©2019 Radio Systems Corporation

1 year warranty

What's included: No Pull Comfort Harness • Product Manual



- Front leash attachment reduces leash pulling
- Five adjustment points for custom fit
- Two leash points provide walking options
- Use with the Premier Pet™ Multi-Functional Leash for more control & walking options

No Pull Comfort Harness



Premier Pet™

Premier Pet™



Premier Pet™



No Pull Comfort Harness

Designed for Maximum Comfort & Safety

- Easy-to-use & fit
- Reflective for increased visibility
- Padded handle is easy to control



APPROX. 15-30 LB.